




INSTRUCTIONS FOR SETTING UP MOTION ALERTS ON THE DMSS APP

Pre-Requisite: have the DMSS app installed on your phone

Step 1.


From DMSS home screen press the three dots to the right of the play button, click “device details”





Step 2.


Select “multi-channel alarm subscription” then on the next page, toggle on the switch.





Step 3.

Select the motion detection option. Then from the next screen select which cameras you want to receive motion alerts from.





Step 4.

Click Back. Then from the next screen click save. Your motion alert are now set up.

